

**TO OUR VALUED CUSTOMER:
PLEASE READ ALL NOTES BEFORE BEGINNING INSTALLATION**

THANK YOU FOR PURCHASING THIS CLASSIC AUTOFUSE SERIES DASH HARNESS. THIS IS THE ONLY FACTORY PLUG & PLAY OEM STYLE DASH HARNESS WITH STATE-OF-THE-ART AUTOFUSE SERIES FUSES. FOR ANY QUESTIONS CONCERNING INSTALLATION OF THIS HARNESS PLEASE CALL OUR TECHNICAL SUPPORT LINE AT (562) 926-9552.


OPTIONAL RELAY CONNECTORS AND TERMINAL KITS, FUSE AND FLASHER KITS, FRONT OF FUSE BLOCK ACCESSORY CONNECTOR AND TERMINAL KITS ARE AVAILABLE SEPARATELY. CALL YOUR AUTHORIZED M&H ELECTRIC DEALER OR OUR DIRECT DIAL LINE ABOVE FOR ASSISTANCE WITH THESE KITS AND MANY OTHER ELECTRICAL PRODUCTS FOR YOUR CLASSIC CAR OR TRUCK.

ALL ROUTING IS LIKE ORIGINAL DASH HARNESS EXCEPT ACCESSORY WIRES. SEE STEP 2 ON PAGE 2 FOR REMOVAL OF BULKHEAD CONNETOR BEFORE BEGINNING INSTALLATION OF DASH HARNESS. IT IS RECOMMENDED THAT YOU PURCHASE A FACTORY ASSEMBLY INSTRUCTION MANUAL (WHEN AVAILABLE) TO ASSIST IN ROUTING HARNESSES THROUGHOUT THE VEHICLE. PROCEED TO INSTALL DASH HARNESS EXCEPT THE 6 NEW ACCESSORY WIRES. THESE WIRES WILL BE COVERED IN STEP 7 OF PAGE 2.

CAUTION: ACCESSORY WIRES MUST NOT BE LEFT BARE. SEE CAUTION BELOW IF ANY OF THE ACCESSORY WIRES WILL NOT BE USED.

NOTE: ALL CONNECTORS ON THESE INSTRUCTION SHEETS ARE VIEWED FROM THE MATING END VIEW OPPOSITE THE WIRE ENTRY SIDE UNLESS OTHERWISE SPECIFIED.


| WIRE | GA. | COLOR | NOTE | WIRE | GA. | COLOR | NOTE | WIRE | GA. | COLOR | NOTE | WIRE | GA. | COLOR | NOTE |
|------|-----|----------------|------------|------|-----|-------------|------------|------|-----|-------------|------------|------|-----|--------------------------|------------|
| 1A | 12 | RED / WHITE | SEE PAGE 8 | 6B | 12 | PURPLE | | 28 | 18 | BLACK | | 75B | 18 | DARK GREEN | |
| 1B | 12 | RED / WHITE | SEE PAGE 8 | 6C | 12 | PURPLE | | 29 | 12 | DARK GREEN | | 91 | 18 | BLACK | |
| 1C | 10 | RED / WHITE | SEE PAGE 8 | 8A | 18 | GRAY | | 30A | 18 | TAN | | 92 | 18 | LIGHT BLUE | |
| 1D | 12 | RED / WHITE | SEE PAGE 8 | 8B | 18 | GRAY | | 30B | 18 | TAN | | 93A | 18 | YELLOW | |
| 1E | 10 | RED / WHITE | | 8C | 18 | GRAY | | 33A | 18 | TAN / BLACK | | 93B | 18 | YELLOW | SEE PAGE 8 |
| 1F | 10 | RED / WHITE | | 8D | 18 | GRAY | SEE PAGE 8 | 33B | 18 | TAN / BLACK | | 94 | 18 | DARK BLUE | |
| 2A | 12 | RED | | 8E | 18 | GRAY | SEE PAGE 8 | 33C | 18 | TAN / BLACK | | 105 | 18 | BLACK | |
| 2B | 12 | RED | SEE PAGE 8 | 9 | 18 | BROWN | | 35 | 18 | DARK GREEN | | 106 | 18 | BLACK / WHITE | |
| 2C | 12 | RED | | 10 | 16 | LIGHT BLUE | | 39A | 18 | PINK | | 130 | 24 | BROWN / WHITE RESISTANCE | |
| 2D | 12 | RED | | 11A | 16 | LIGHT GREEN | | 39B | 18 | PINK | | 140A | 16 | ORANGE | |
| 2E | 12 | RED | | 11B | 16 | LIGHT GREEN | SEE PAGE 8 | 39C | 16 | PINK | SEE PAGE 8 | 140B | 14 | ORANGE | SEE PAGE 8 |
| 2F | 12 | RED | | 12 | 16 | TAN | | 39D | 16 | PINK | SEE PAGE 8 | 140C | 14 | ORANGE | SEE PAGE 8 |
| 2G | 14 | RED | SEE PAGE 8 | 14A | 18 | LIGHT BLUE | | 39M | 18 | PINK | | 141 | 18 | BROWN / WHITE | |
| 3A | 12 | PINK | | 14B | 18 | LIGHT BLUE | | 39T | 14 | PINK | | 150A | 18 | BLACK | |
| 3B | 12 | PINK | | 15A | 18 | DARK BLUE | | 40A | 18 | ORANGE | | 150B | 18 | BLACK | |
| 3C | 12 | PINK | SEE PAGE 8 | 15B | 18 | DARK BLUE | | 40B | 14 | ORANGE | SEE PAGE 8 | 150C | 18 | BLACK | |
| 3D | 14 | PINK | SEE PAGE 8 | 16 | 18 | PURPLE | | 40C | 16 | ORANGE | | 150D | 18 | BLACK | |
| 3E | 14 | PINK | SEE PAGE 8 | 17 | 18 | WHITE | | 40D | 18 | ORANGE | | 156 | 18 | WHITE | |
| 4A | 12 | BROWN | SEE PAGE 8 | 18 | 18 | YELLOW | SEE PAGE 8 | 40E | 14 | ORANGE | SEE PAGE 8 | 200 | 12 | LIGHT GREEN / BLACK | |
| 4B | 14 | BROWN | SEE PAGE 8 | 19 | 18 | DARK GREEN | | 43 | 18 | YELLOW | | 201 | 12 | DARK GREEN / RED | |
| 4C | 18 | BROWN | SEE PAGE 8 | 24A | 18 | LIGHT GREEN | | 44 | 16 | DARK GREEN | | 202 | 12 | BLACK / RED | |
| 5A | 12 | PURPLE / WHITE | | 24B | 18 | LIGHT GREEN | | 50A | 14 | BROWN | | 203 | 12 | RED / BLACK | |
| 5B | 12 | PURPLE / WHITE | | 27 | 16 | BROWN | SEE PAGE 8 | 50B | 14 | BROWN | SEE PAGE 8 | 204 | 10 | ORANGE / BLACK | |
| 5C | 12 | PURPLE / WHITE | | 27A | 18 | BROWN | SEE PAGE 8 | 75A | 18 | DARK GREEN | | 300 | 12 | ORANGE | |
| 6A | 12 | PURPLE | | | | | | | | | | | | | |



M&H Electric Fabricators, Inc.
13537 Alondra Blvd. Santa Fe Springs, CA 90670
 Phone (562) 926-9552 Fax (562) 926-9572


INSTRUCTION SHEET
 CLASSIC AUTO FUSE SERIES DASH HARNESS

PAGE 1 OF 9 **92969034** SIZE **B**



STEP 7
 WHEN USING FIREWALL PASS THRU CONNECTOR, GROMMET MAY BE LOCATED ON FLAT SURFACE OF FIREWALL CLEAR OF FUSE BLOCK AND EXISTING COMPONENTS. (SEE PAGES 3, 4 & 5) DRILL 1 1/8 INCH HOLE FOR GROMMET. MAKE SURE GROMMET HOLE IS LOCATED WITHIN REACH OF FIREWALL PASS THRU CONNECTOR ON DASH SIDE. SEE PAGES 3, 4 & 5 FOR ACCESSORY WIRE CONNECTION INSTRUCTIONS.

STEP 2
 REMOVE ENGINE AND FORWARD LAMP HARNESS BULKHEAD CONNECTORS
 NOTE: AFTER REMOVING ENGINE AND FORWARD LAMP HARNESS BULKHEAD CONNECTORS IT MAY BE NECESSARY TO SEPARATE THE ENGINE HARNESS BULKHEAD CONNECTOR FROM THE FORWARD LAMP HARNESS BULKHEAD CONNECTOR BY GENTLY PRYING THEM APART WITH A SMALL FLAT SCREWDRIVER.



STEP 6
 RE-INSTALL ENGINE AND FORWARD LAMP HARNESS BULKHEAD CONNECTORS. NOTE: THEY MUST BE PRE-ASSEMBLED PRIOR TO BOLTING TO FIREWALL.

STEP 4
 BIG BLOCK ENGINES MUST BE ROUTED ALONG TOP SIDE OF ENGINE AS SHOWN

STEP 4
 ROUTE POWER FEED EXTENSION WIRE WITH FUSIBLE LINK ALONG WITH ENGINE WIRING HARNESS AS SHOWN.

STEP 4
 LOOP EXCESS WIRE LOOM AND SECURE AS REQUIRED (SMALL BLOCK ENGINES ONLY)

STEP 3
 INSTALL POWER FEED EXTENSION WIRE WITH FUSIBLE LINK INTO ENGINE HARNESS BULKHEAD CONNECTOR. SEE DETAIL 1 VIEW A.

TYPICAL MOUNTING LOCATION OF RELAYS FOR ACCESSORIES SUCH AS FANS, ETC.

EXISTING ORIGINAL ENGINE HARNESS FOR SMALL BLOCK

STARTER MOTOR

STEP 5
 ATTACH POWER FEED EXTENSION WIRE WITH FUSIBLE LINK ALONG WITH BATTERY CABLE ON STARTER AS SHOWN.

BATTERY CABLE ON 3/8" STUD (LARGE ONE)

EXISTING ORIGINAL ENGINE HARNESS FOR BIG BLOCK

STEP 1
 REMOVE NEGATIVE BATTERY CABLE.

**** CAUTION ****
 THE POWER FEED EXTENSION WIRE ADDS EXTRA CAPACITY TO THE FUSEBLOCK AND REQUIRES THAT THE BATTERY CABLES BE AT LEAST 4 GAUGE OR LARGER.

ACCESSORY WIRE(S) FOR RELAYS OR ACCESSORY COMPONENTS SUCH AS ELECTRIC FANS, ETC.

SEE SEAL NOTE ON STEP 7.

STEP 1:
 REMOVE NEGATIVE BATTERY CABLE.

STEP 2:
 REMOVE FORWARD LAMP HARNESS AND ENGINE HARNESS BULKHEAD CONNECTORS BY REMOVING ATTACHING BOLT.
 NOTE: AFTER REMOVING ENGINE AND FORWARD LAMP HARNESS BULKHEAD CONNECTORS IT MAY BE NECESSARY TO SEPARATE THE ENGINE HARNESS BULKHEAD CONNECTOR FROM THE FORWARD LAMP HARNESS BULKHEAD CONNECTOR BY GENTLY PRYING THEM APART WITH A SMALL FLAT SCREWDRIVER.

STEP 3:
 INSERT THE POWER FEED EXTENSION WIRE WITH FUSIBLE LINK INTO THE APPROPRIATE CAVITIES ON THE ENGINE HARNESS BULKHEAD CONNECTOR. SEE DETAIL 1 VIEW A.

NOTE: IT MAY BE NECESSARY TO CLEAN THE CAVITIES IN THE BULKHEAD CONNECTOR WITH A SMALL SCREWDRIVER AND RE-SEAL WITH BLACK SILICONE AFTER INSTALLATION OF POWER FEED WIRE.

STEP 4:
 ROUTE POWER FEED EXTENSION WIRE WITH FUSIBLE LINK ALONG WITH ENGINE WIRING HARNESS AS SHOWN IN DIAGRAM.

NOTE: SMALL BLOCK ENGINES ARE ROUTED DOWN THE BACK SIDE OF THE ENGINE AND THE EXCESS WIRE FROM THE POWER FEED EXTENSION WIRE MUST BE LOOPED AND SECURED AS SHOWN. USE CAUTION NOT TO KINK LOOM AND KEEP AWAY FROM EXHAUST OR HEAT. BIG BLOCK ENGINES ARE ROUTED OVER THE TOP ALONG SIDE THE VALVE COVER WITH NO EXCESS WIRE AS SHOWN. CAREFULLY ROUTE BELOW EXHAUST MANIFOLD BY OIL PAN RAIL TO STARTER. SECURE IF NECESSARY.

CAUTION: THE POWER FEED CIRCUIT ADDS EXTRA CAPACITY TO THE NEW FUSEBLOCK AND REQUIRES THAT THE VEHICLE BATTERY CABLE BE AT LEAST 4 GAUGE OR LARGER.

STEP 5:
 INSTALL RING TERMINAL END OF POWER FEED EXTENSION WIRE WITH FUSIBLE LINK ONTO STARTER BATTERY POST (LARGE ONE) WITH BATTERY CABLE AS SHOWN.

STEP 6:
 RE-INSTALL ENGINE HARNESS AND FORWARD LAMP HARNESS BULKHEAD CONNECTORS ONTO DASH BULKHEAD CONNECTOR ON FIREWALL.

NOTE: DO NOT RE-INSTALL NEGATIVE BATTERY CABLE UNTIL ALL ACCESSORIES HAVE BEEN INSTALLED OR ADDRESSED IN PRECEDING PAGES.

STEP 7:
 THERE ARE 3 WAYS TO USE THE NEW ACCESSORY CONNECTORS & WIRES ON YOUR NEW CLASSIC AUTOFUSE SERIES DASH HARNESS:



1. YOU CAN USE THE 6-WAY CONNECTOR AS AN IN-LINE STYLE WHEN NO WIRES WILL BE PASSING THROUGH THE FIREWALL TO THE ENGINE COMPARTMENT.
2. YOU CAN USE THE 6-WAY CONNECTOR WITH THE GROMMET AS A PANEL MOUNT STYLE WHEN ALL THE WIRES WILL PASS THROUGH THE FIREWALL TO THE ENGINE COMPARTMENT.
3. YOU CAN USE THE 6-WAY CONNECTOR WITH THE GROMMET AS A PANEL MOUNT STYLE AND THE 4-WAY CONNECTOR AS AN IN-LINE CONNECTOR WHEN SOME WIRES WILL PASS THROUGH THE FIREWALL AND SOME WIRES WILL BE USED AS IN-LINE UNDER THE DASH.

SEAL NOTE: SEAL ANY UNUSED CAVITIES ON THE ENGINE SIDE OF THE 6-WAY CONNECTOR WITH SILICONE.

INSTALL THE 6-WAY CONNECTOR AND GROMMET INTO THE FIREWALL BY DRILLING A 1 " HOLE IN THE FIREWALL AND INSTALLING GROMMET. MAKE SURE GROMMET HOLE IS LOCATED WITHIN REACH OF 6-WAY ACCESSORY HARNESS CONNECTOR ON DASH HARNESS BY SCREWING THE NEW FUSEBLOCK IN PLACE FIRST TO DETERMINE THE LENGTH AND POSITION OF THE ACCESSORY WIRES AND CONNECTORS.


M&H Electric Fabricators, Inc.
 AUTOMOTIVE WIRING SYSTEMS
 13537 Alondra Blvd. Santa Fe Springs, CA 90670
 Phone (562) 926-9552 Fax (562) 926-9572

INSTRUCTION SHEET
 POWER FEED EXTENSION WIRE WITH FUSIBLE LINK



VIEW A
 WIRE ENTRY VIEW OF ENGINE BULKHEAD CONNECTOR

INSTALL POWER FEED EXTENSION WIRES WITH FUSIBLE LINK INTO CAVITIES AS SHOWN FROM WIRE ENTRY SIDE OF CONNECTOR. WIRES MAY BE REVERSED IN CAVITIES.



| WIRE | GA. | COLOR |
|------|-----|------------------------|
| 1G | 12 | BLUE DARK FUSIBLE LINK |
| 1J | 10 | RED / WHITE |
| 1K | 10 | RED / WHITE |

TO BATTERY POST TERMINAL ON STARTER

POWER FEED EXTENSION WIRE WITH FUSIBLE LINK TO ENGINE HARNESS BULKHEAD CONNECTOR INSTALLATION


CAUTION: THIS CIRCUIT ADDS EXTRA CAPACITY TO THE NEW FUSEBLOCK AND REQUIRES THAT THE VEHICLE BATTERY CABLE BE AT LEAST 4 GAUGE OR LARGER.

DETAIL 1

DEVICE WIRE ASSEMBLES

SEE
DETAIL
1 & 2


| WIRE | GA. | COLOR |
|------|-----|---------------------|
| 200A | 12 | LIGHT GREEN / BLACK |
| 201A | 12 | DARK GREEN / RED |
| 202A | 12 | BLACK / RED |
| 203A | 12 | RED / BLACK |
| 204A | 10 | ORANGE / BLACK |



THESE WIRES ARE PROVIDED TO REACH RELAYS MOUNTED IN THE MOST COMMON MOUNTING LOCATIONS. WIRES FROM RELAYS TO ACTUAL ACCESSORIES ARE NOT PROVIDED AND ARE THE RESPONSIBILITY OF THE CUSTOMER.

SEE
DETAIL
1 & 2


| WIRE | GA. | COLOR |
|------|-----|-------|
| 39N | 14 | PINK |
| 39P | 18 | PINK |
| 39R | 18 | PINK |
| 39S | 18 | PINK |



(39P) UNDEFINED ACCESSORY WHEN USED AS IN-LINE UNDER DASH COMBINED WITH FIREWALL PASS THROUGH TO ENGINE COMPARTMENT.
 (39R) UNDEFINED ACCESSORY
 (39S) UNDEFINED ACCESSORY

SEE
DETAIL
1 & 2

| WIRE | GA. | COLOR |
|------|-----|-------|
| 39E | 14 | PINK |
| 39F | 18 | PINK |
| 39G | 18 | PINK |
| 39H | 18 | PINK |
| 39J | 18 | PINK |
| 39K | 18 | PINK |
| 39L | 18 | PINK |




(39F) TO ELECTRIC WATER PUMP RELAY COIL (+)
 (39G) TO ELECTRIC FUEL PUMP RELAY COIL (+)
 (39H) TO ELECTRIC FAN 1 RELAY COIL (+)
 (39J) TO ELECTRIC FAN 2 RELAY COIL (+)
 (39K) UNDEFINED ACCESSORY
 (39L) UNDEFINED ACCESSORY

IGNITION POWER WITH SWITCH IN RUN POSITION ONLY. USED TO POWER RELAY COILS FOR ACCESSORIES WHEN IGNITION SWITCH IS TURNED ON. SEE PAGES 4 & 5. ALL WIRES ARE THE SAME AND CAN BE INTERCHANGED.

****CAUTION****
 THESE WIRES ARE LIVE
 UNUSED WIRES MUST BE CUT OFF AT THE END OF TAPE OR INSULATE THE ENDS OF THE WIRES.


IGNITION FEED WIRE ASSEMBLY

THIS 6-WAY CONNECTOR IS USED TO PASS WIRES THROUGH THE FIREWALL TO THE ENGINE COMPARTMENT OR IT CAN BE USED AS AN IN-LINE CONNECTOR UNDER DASH WITHOUT THE GROMMET.




DETAIL 1



USE THIS 4-WAY CONNECTOR AS AN UNDER DASH IN-LINE CONNECTOR FOR WIRES THAT DO NOT HAVE TO PASS THROUGH THE FIREWALL.



DETAIL 2



DETAIL 3



DETAIL 4

** CAUTION **

WHEN DESIGNING OR LAYING OUT YOUR ACCESSORIES FOR THE VEHICLE, IT IS POSSIBLE TO OVERLOAD THE DASH HARNESS IF THE CURRENT DRAW OF ANY ACCESSORIES EXCEEDS THE PRINTED FUSE OR CIRCUIT BREAKER CAPACITY OF THE CAVITY. PLEASE CALL OUR TECHNICAL SUPPORT FOR HELP BEFORE ANY DEVIATION FROM THE RATED AMPERAGE CAPACITY OF THE FUSE OR CIRCUIT BREAKER CAVITY.


M&H Electric Fabricators, Inc.
 AUTOMOTIVE WIRING SYSTEMS

13537 Alondra Blvd. Santa Fe Springs, CA 90670
 Phone (562) 926-9552 Fax (562) 926-9572

INSTRUCTION SHEET
 ACCESSORY WIRE HARNESS

TYPICAL WIRING INSTRUCTIONS FOR INSTALLING A SINGLE ELECTRIC RADIATOR FAN

SCHEMATIC DIAGRAM 1



TYPICAL EXAMPLE OF SINGLE ELECTRIC FAN WIRING. RELAY ACTIVE WITH KEY IN RUN POSITION ONLY AND TEMPERATURE SENDER TRIGGERED.

DO NOT REMOVE ANY LETTERING UNTIL SYSTEM HAS BEEN FULLY TESTED

CAUTION: BE CAREFUL TO ONLY REMOVE INDICATED LETTERING WITHOUT REMOVING OTHER LETTERING. ACETONE WILL REMOVE ANY LETTERING THAT IT TOUCHES.

DETAIL 1
SINGLE ELECTRIC FAN FUSE CAVITY


NOTE: RELAYS, RELAY CONNECTORS, SWITCHES PUMPS AND FANS ARE NOT PROVIDED WITH THIS KIT.

WIRING INSTRUCTIONS FOR INSTALLING SINGLE ELECTRIC RADIATOR FAN

- STEP 1: INSTALL SINGLE ELECTRIC FAN WIRING ACCORDING TO SCHEMATIC DIAGRAM 1.
- STEP 2: DETERMINE THE AMPERAGE RATING OF YOUR ELECTRIC FAN AND CHOOSE THE APPROPRIATE FUSE FOR THE "ELEC FAN 1" CAVITY ON THE FUSEBLOCK.
- STEP 3: FULLY TEST THE SYSTEM.
- STEP 4: REMOVE APPROPRIATE LETTERING ON FUSEBLOCK. SEE DETAIL 1.

TYPICAL WIRING INSTRUCTIONS FOR INSTALLING DUAL ELECTRIC RADIATOR FANS.

SCHEMATIC DIAGRAM 2



TYPICAL EXAMPLE OF DUAL ELECTRIC FAN WIRING. RELAY ACTIVE WITH KEY IN RUN POSITION ONLY AND TEMPERATURE SENDER TRIGGERED.

DO NOT REMOVE ANY LETTERING UNTIL SYSTEM HAS BEEN FULLY TESTED

CAUTION: BE CAREFUL TO ONLY REMOVE INDICATED LETTERING WITHOUT REMOVING OTHER LETTERING. ACETONE WILL REMOVE ANY LETTERING THAT IT TOUCHES.


DETAIL 2
DUAL ELECTRIC FANS FUSE CAVITIES

WIRING INSTRUCTIONS FOR INSTALLING DUAL ELECTRIC RADIATOR FANS

- STEP 1: INSTALL DUAL ELECTRIC FAN WIRING ACCORDING TO SCHEMATIC DIAGRAM 2.
- STEP 2: DETERMINE THE AMPERAGE RATING OF YOUR ELECTRIC FANS AND CHOOSE THE APPROPRIATE FUSE FOR THE "ELEC FAN 1" & "ELEC FAN 2" CAVITIES ON THE FUSEBLOCK.
- STEP 3: FULLY TEST THE SYSTEM.
- STEP 4: REMOVE APPROPRIATE LETTERING ON FUSEBLOCK. SEE DETAIL 2.



INSTRUCTION SHEET ACCESSORY WIRING SCHEMATIC



ELECTRIC FUEL PUMPS THAT DRAW APPROXIMATELY 10 TO 17 AMPS USE 20 AMP FUSE IN "ELEC FUEL PMP" CAVITY ON FUSE BLOCK. REMOVE "25A" FROM FUSE BLOCK USING ACETONE OR RAZOR BLADE. (SEE DETAIL 3)


ELECTRIC FUEL PUMPS THAT DRAW MORE THAN 17 AMPS USE 25A FUSE IN "ELEC FUEL PMP" CAVITY ON FUSE BLOCK. REMOVE "20A" FROM FUSE BLOCK USING ACETONE OR RAZOR BLADE. (SEE DETAIL 3)

**SCHEMATIC
DIAGRAM
3**

TYPICAL EXAMPLE OF FUEL PUMP WIRING WITHOUT RELAY.

**WIRING INSTRUCTIONS FOR INSTALLING
ELECTRIC FUEL PUMP WITHOUT RELAY**

STEP 1:
INSTALL ELECTRIC FUEL PUMP WIRING ACCORDING TO SCHEMATIC DIAGRAM 3.




ELECTRIC FUEL PUMPS THAT DRAW APPROXIMATELY 10 TO 17 AMPS USE 20 AMP FUSE IN "ELEC FUEL PMP" CAVITY ON FUSE BLOCK. REMOVE "25A" FROM FUSE BLOCK USING ACETONE OR RAZOR BLADE. (SEE DETAIL 3)

ELECTRIC FUEL PUMPS THAT DRAW MORE THAN 17 AMPS USE 25A FUSE IN "ELEC FUEL PMP" CAVITY ON FUSE BLOCK. REMOVE "20A" FROM FUSE BLOCK USING ACETONE OR RAZOR BLADE. (SEE DETAIL 3)

**SCHEMATIC
DIAGRAM
4**

**TYPICAL EXAMPLE OF FUEL PUMP WIRING,
RELAY ACTIVE WITH KEY IN RUN POSITION ONLY.**



**WIRING INSTRUCTIONS FOR INSTALLING
ELECTRIC FUEL PUMP WITH RELAY**

STEP 1:
INSTALL ELECTRIC FUEL PUMP WIRING ACCORDING TO SCHEMATIC DIAGRAM 4.

STEP 2:
DETERMINE THE AMPERAGE RATING OF YOUR ELECTRIC FUEL PUMP AND CHOOSE THE APPROPRIATE FUSE FOR THE "ELEC FUEL PMP" CAVITY ON THE FUSEBLOCK. SEE DETAIL 3.

STEP 3:
FULLY TEST THE SYSTEM.

STEP 4:
REMOVE APPROPRIATE LETTERING ON FUSEBLOCK. SEE DETAIL 3.


**WIRING INSTRUCTIONS FOR INSTALLING
ELECTRIC WATER PUMP WITH RELAY**

STEP 1:
INSTALL ELECTRIC WATER PUMP WIRING ACCORDING TO SCHEMATIC DIAGRAM 5.

STEP 2:
DTERMINE THE AMPERAGE RATING OF YOUR ELECTRIC WATER PUMP AND CHOOSE THE APPROPRIATE FUSE FOR THE "ELEC WTR PMP" CAVITY ON THE FUSEBLOCK. SEE DETAIL 4.

STEP 3:
FULLY TEST THE SYSTEM.

STEP 4:
REMOVE APPROPRIATE LETTERING ON FUSEBLOCK. SEE DETAIL 4.




ELECTRIC WATER PUMPS THAT DRAW 13 AMPS OR LESS USE 15 AMP FUSE IN THE "ELEC WTR PMP" CAVITY ON THE FUSE BLOCK. REMOVE "20A" FROM FUSE BLOCK USING ACETONE OR RAZOR BLADE. (SEE DETAIL 4)

ELECTRIC WATER PUMPS THAT DRAW MORE THAN 13 AMPS USE 20 AMP FUSE IN THE "ELEC WTR PMP" CAVITY ON THE FUSE BLOCK. REMOVE "15A" FROM FUSE BLOCK USING ACETONE OR RAZOR BLADE. (SEE DETAIL 4)

**SCHEMATIC
DIAGRAM
5**


**TYPICAL EXAMPLE OF ELECTRIC WATER PUMP WIRING
RELAY ACTIVE WITH KEY IN RUN POSITION.**







**DETAIL 4
ELECTRIC WATER PUMP FUSE CAVITY**



**INSTRUCTION SHEET
ACCESSORY WIRING SCHEMATIC**



USE THIS CONNECTOR FOR OTHER FACTORY ACCESSORIES THAT REQUIRE THE SAME CAVITY ON THE FUSEBLOCK WITH FACTORY TYPE ACCESSORIES. THE FINAL TERMINATING ACCESSORY WILL NOT HAVE THIS ACCESSORY CONTINUATION JUMPER.



THESE INSTRUCTIONS ARE FOR ADAPTING EXISTING AIR CONDITIONING HARNESS TO ATO ADAPTER WIRE.

DETAIL 1


DETAIL A

M&H Electric Fabricators, Inc.
 AUTOMOTIVE WIRING SYSTEMS
 13537 Alondra Blvd. Santa Fe Springs, CA 90670
 Phone (562) 926-9552 Fax (562) 926-9572

INSTRUCTION SHEET
 ACCESSORY ADAPTER WIRES

PAGE 6 OF 9 **92969034** SIZE B

THIS LOOSE PIECE CONNECTOR AND TERMINAL IS PROVIDED FOR "PWR ACC 1" OUTPUT CAVITY ON FRONT OF FUSEBLOCK. TERMINAL MUST BE HAND CRIMPED & SOLDERED TO WIRE.



BLUE CONNECTOR


TERMINAL

THIS CAVITY IS DEDICATED FOR A SECOND POWER ACCESSORY OPTION WHEN THE CIRCUIT BREAKER CAVITY IS USED OR FOR A SMALLER POWER ACCESSORY OPTION AS THIS CAVITY IS RATED AT EITHER 20 OR 30 AMPS. IT CAN BE USED FOR POWER ACCESSORY OPTIONS SUCH AS POWER SEATS, POWER WINDOWS, POWER LOCKS AND OTHER ACCESSORIES. SEE DETAIL 2.

CAUTION: DO NOT INSERT FUSE IN "PWR ACC 1" CAVITY IF THIS OPTION IS NOT USED.

NOTE: SEE DETAIL 1 IF ONLY A SINGLE POWER ACCESSORY OPTION WILL BE USED OR FOR LARGER AMPERAGE REQUIREMENTS FROM 30 TO 40 AMPS.

DO NOT REMOVE ANY LETTERING UNTIL SYSTEM HAS BEEN FULLY TESTED



REMOVE 20A WHEN USING 30 AMP CIRCUIT BREAKER OR FUSE. REMOVE LETTERING WITH RAZOR BLADE OR ACETONE.


REMOVE 30A WHEN USING 20 AMP CIRCUIT BREAKER OR FUSE.

CAUTION: BE CAREFUL TO ONLY REMOVE INDICATED LETTERING WITHOUT REMOVING OTHER LETTERING. ACETONE WILL REMOVE ANY LETTERING THAT IT TOUCHES.

DETAIL 2

POWER ACCESSORY FUSE CAVITY

DO NOT REMOVE ANY LETTERING UNTIL SYSTEM HAS BEEN FULLY TESTED




REMOVE 30A WHEN USING 40 AMP CIRCUIT BREAKER OF FUSE. REMOVE 40A WHEN USING 30 AMP CIRCUIT BREAKER OF FUSE. REMOVE LETTERING WITH RAZOR BLADE OR ACETONE.

CAUTION: BE CAREFUL TO ONLY REMOVE INDICATED LETTERING WITHOUT REMOVING OTHER LETTERING. ACETONE WILL REMOVE ANY LETTERING THAT IT TOUCHES.

DETAIL 1

POWER ACCESSORY CIRCUIT BREAKER CAVITY



THIS IS A DEDICATED CAVITY FOR A SINGLE ELECTRIC RADIATOR FAN OR OTHER ACCESSORY. SEE PAGES 3 & 4 CIRCUIT 39H. CAUTION: DO NOT INSERT FUSE IN CAVITY IF THIS OPTION IS NOT USED.

THIS IS A DEDICATED CAVITY FOR A SECOND RADIATOR FAN OR OTHER ACCESSORY. SEE PAGES 3 & 4 CIRCUIT 39J. CAUTION: DO NOT INSERT FUSE IN CAVITY IF THIS OPTION IS NOT USED.

THIS IS A DEDICATED CAVITY FOR AN ELECTRIC FUEL PUMP OR OTHER ACCESSORY. SEE PAGES 3 & 5 CIRCUIT 39G. CAUTION: DO NOT INSERT FUSE IN CAVITY IF THIS OPTION IS NOT USED.


THIS IS A DEDICATED CAVITY FOR AN ELECTRIC WATER PUMP DRIVE OR OTHER ACCESSORY. SEE PAGES 3 & 5 CIRCUIT 39F. CAUTION: DO NOT INSERT FUSE IN CAVITY IF THIS OPTION IS NOT USED.

14 ACCESSORY CAVITIES TO ACCOMODATE EXISTING ACCESSORIES AS WELL AS NEW ACCESSORY OPTIONS SEE PAGE 6.

THIS IS A DEDICATED CAVITY FOR A SINGLE POWER ACCESSORY OPTION SUCH AS POWER WINDOWS, POWER LOCKS, POWER SEATS OR OTHER ACCESSORIES. THIS CAVITY IS DESIGNED FOR A CIRCUIT BREAKER BUT A FUSE MAY BE USED. ALWAYS ORGANIZE THE LARGEST AMPERAGE DRAW POWER ACCESSORY OPTION ON THIS CAVITY. SEE DETAIL 1. CAUTION: DO NOT INSERT CIRCUIT BREAKER OR FUSE IF THIS OPTION IS NOT USED. NOTE: IF A SECOND POWER ACCESSORY OPTION IS USED THEN USE THE "PWR ACC 1" CAVITY.


40356
FUSE & FLASHER KIT
 1973-74 TRUCKS

- (2) - FLASHER 552
- (4) - ATO 15 AMP FUSE
- (9) - ATO 20 AMP FUSE
- (2) - ATO 4 AMP FUSE
- (2) - ATO 3 AMP FUSE
- (5) - ATO 25 AMP FUSE
- (2) - ATO 30 AMP FUSE
- (4) - ATO 10 AMP FUSE
- (1) - ATO TYPE 30 AMP CIRCUIT BREAKER
- (1) - ATO TYPE 40 AMP CIRCUIT BREAKER




41355
11-WAY CONNECTOR KIT
 ALL MODELS

- (1) - 11-WAY FEMALE CONNECTOR
- (1) - 11-WAY MALE CONNECTOR
- (11) - 14/16 GAUGE FEMALE TERMINAL
- (11) - 10/12 GAUGE FEMALE TERMINAL
- (2) - 14/16 GAUGE MALE TERMINAL
- (2) - 10/12 GAUGE MALE TERMINAL



11-WAY FEMALE CONNECTOR


14-16-18 GA FEMALE TERMINAL
 12 GA FEMALE TERMINAL



11-WAY MALE CONNECTOR


14-16-18 GA MALE TERMINAL
 12 GA MALE TERMINAL

41358
FRONT OF FUSEBLOCK
ACCESSORY CONNECTOR
& TERMINALS KIT
 1967-78 TRUCKS




14-16-18 GA MALE TERMINAL
 12-10 GA MALE TERMINAL

41359
6-WAY ACCESSORY
FUSEBLOCK KIT




6-WAY ACCESSORY FUSEBLOCK




14-16-18 GA TERMINAL BUS BAR
 12-10 GA TERMINAL BUS BAR

(COMING SOON)
SPARE FUSE HOLDER
 ALL MODELS



41356
RELAY & CONNECTOR KIT
 ALL MODELS

- (1) - 12033871 5-WAY RELAY CONNECTOR
- (1) - SECONDARY LOCK FOR RELAY CONNECTOR
- (1) - RELAY
- (3) 14-16-18 GA FEMALE TERMINAL
- (2) 10-12 GA FEMALE TERMINAL



SEE PAGE 7 FOR THE FOLLOWING
 FUSE BLOCK KIT APPLICATIONS:

40356
 41358

SEE PAGE 8 FOR THE FOLLOWING
 FUSE BLOCK KIT APPLICATIONS:

41355
 41356
 41359
 SPARE FUSE HOLDER (COMING SOON)

M&H Electric Fabricators, Inc.
 AUTOMOTIVE WIRING SYSTEMS

13537 Alondra Blvd. Santa Fe Springs, CA 90670
 Phone (562) 926-9552 Fax (562) 926-9572

INSTRUCTION SHEET
 AVAILABLE KITS