



M&H ELECTRIC FABRICATORS, INC.
AUTOMOTIVE WIRING SYSTEMS

13537 Alondra Blvd. Santa Fe Springs CA 90670
Phone (562) 926-9552 Fax (562) 926-9572

INSTRUCTION SET 92963714 #35816 REV 1.1 7/13/95

©2001 M&H Electric Fabricators, Inc. All rights reserved. The design and documents included in this assembly are the exclusive property of M&H Electric Fabricators, Inc. No part of the design or documentation may be reproduced without the express permission of M&H Electric Fabricators, Inc.

92963714

WIRE USAGE CHART

92963714

WIRE	WIRE COLOR	GA.	CIRCUIT DESCRIPTION
18	yellow	18	Steering column connector to turn signal flasher
19	white	18	Steering column connector to stop lamp switch connector
20	brown	18	Rear body connector fuel sender lead to fuel gauge
21	pink	18	Rear body connector left hand directional lead wire to steering column connector
22	black	18	Rear body connector to "TAIL" terminal on headlight switch
23	purple	18	Rear body connector right hand directional lead wire to steering column connector
24	tan	18	Front light harness connector to low beam terminal on dimmer switch

1 a	red	12	Front light harness connector to in-line battery power splice
1 b	red	16	Accessory fuse panel "BAT" terminal to in-line battery power splice
1 c	red	14	"BAT" terminal on headlight switch to in-line battery power splice
1 d	red	12	In-line battery power splice to "BAT" terminal on ignition switch
1 f	red	18	In-line battery power splice to clock
2	yellow	18	"BAT" terminal on dimmer switch to "HEAD" terminal on headlight switch
3	purple	18	Front light harness connector to "PARK" terminal on headlight switch
4 a	lt green	18	Front light harness connector to high beam terminal on dimmer switch
4 b	lt green	18	Front light harness connector to headlight high beam indicator light
5	dk green	18	Front light harness connector to horn button connector

This layout is for instruction sheets by wire number and wire suffix

WIRE USAGE CHART

92963 / 14

WIRE	WIRE COLOR	GA.	CIRCUIT DESCRIPTION
6a	lt blue	18	Front light harness connector left directionals to steering column connector
6b	lt blue	18	Dash left directional indicator light to steering column connector
7a	dk blue	18	Front light harness connector right directionals to steering column connector
7b	dk blue	18	Dash right directional indicator light to steering column connector
8a	pink	14	Accessory fuse panel "IGN" terminal to In-line Ignition power splice
8b	pink	18	Temperature gauge "+" terminal to In-line Ignition power splice
8c	pink	18	Fuel gauge "+" terminal to In-line Ignition power splice
8d	pink	18	In-line Ignition power splice to turn signal flasher
8e	pink	14	In-line Ignition power splice to "ACC" terminal on Ignition switch
9	dk green	18	Temperature gauge to temperature sender connection
10	brown	16	Accessory fuse panel "HEATER" terminal to heater switch
11	brown	16	Heater switch to heater blower motor
13a	gray	16	"PANEL" terminal on headlight switch to In-line Instrument light splice
13b	gray	18	Dash light to In-line Instrument light splice
13c	gray	18	In-line Instrument light splice to dash light
13d	gray	18	In-line Instrument light splice to dash light
13e	gray	18	In-line Instrument light splice to heater light
13f	gray	18	In-line Instrument light splice to Ignition switch light
13g	gray	18	In-line Instrument light splice to radio light
13h	gray	18	In-line Instrument light splice to clock light
14	brown	18	"IGN 1" terminal on Ignition switch to generator Indicator light
15	brown	18	Front light harness connector to generator Indicator light
16a	orange	18	"STOP" terminal on headlight switch to rear body connector
16b	orange	18	"STOP" terminal on headlight switch to stop lamp switch connector
16c	red	18	Stop lamp switch connector to glove box light
17	white	18	Rear body connector to "DOME" terminal on headlight switch

This layout is for instruction sheets by wire number and wire suffix