



M&H ELECTRIC FABRICATORS, INC.

13537 Alondra Blvd. Santa Fe Springs CA 90670
 Phone (562) 828-8552 Fax (562) 828-8572

INSTRUCTION SET 92963728 # 35830 REV 1.1 8/1/95

The design and documents included in this assembly are the exclusive property of M&H Electric Fabricators, Inc. No part of the M&H design or documentation may be reproduced without the express permission of M&H Electric Fabricators, Inc.

92963728

WIRE USAGE CHART

92963728

<u>WIRE</u>	<u>WIRE COLOR</u>	<u>GA.</u>	<u>CIRCUIT DESCRIPTION</u>
1	black	10	Starter "BAT" terminal to ignition switch "BAT" terminal
2	purple	14	Starter "SOL" terminal to ignition switch "SOL" terminal
3a	dk green	18	Ignition switch to coil "+" terminal
3b	dk green	18	Ignition switch to ballast resistor
4a	brown	18	Ignition switch to ballast resistor
4b	brown	18	Ignition switch to oil pressure indicator light
5	dk blue	18	Oil pressure sender to oil pressure indicator light
6	dk green	16	Temperature sender to temperature gauge terminal
7	dk green	16	A/C compressor to evaporator control switch