



M&H ELECTRIC
FABRICATORS, INC.

13537 Alondra Blvd. Santa Fe Springs CA 90670
Phone (562) 929-6252 Fax (562) 929-6572

INSTRUCTION SET 92963732 # 35834 REV 1.1 8/1/95

The design and documents included in this assembly are the exclusive property of M&H Electric Fabricators, Inc. No part of the M&H design or documentation may be reproduced without the express permission of M&H Electric Fabricators, Inc.

92963732

WIRE USAGE CHART

92963732

<u>WIRE</u>	<u>WIRE COLOR</u>	<u>GA.</u>	<u>CIRCUIT DESCRIPTION</u>
1	black	10	Starter "BAT" terminal to ignition switch "BAT" terminal
6	purple	12	Neutral safety switch to ignition switch
7	purple	12	Starter "SOL" terminal to neutral safety switch
2	dk blue	18	Oil pressure sender to oil pressure indicator light
3A	dk green	18	Coil "+" terminal to ballast resistor
3B	dk green	18	Starter "RES" terminal to ballast resistor
4	dk green	18	Temperature sender to temperature gauge terminal
5A	tan	18	Ignition switch to ballast resistor
5B	tan	18	Ignition switch to oil pressure indicator light